
## GARDEN 24 Ljussensor/Timer 106936

## Technical Data


Voltage	24V
IP Class	IP 44





Markslojd AB Gränevägen 5 S-511 62 Skene Sweden www.markslojd.com





## Note:

- 1. Device not flashing means light sensor start to work;
- 2. Device in slow flash means light sensor is off;
- 3.Device in fast flash 3 times means light sensor is in Timer function;
- 4. Disable the Timer function by setting the timer to '00'. Here the light will be on at dusk and off at dawn.
- 5.Disable the light sensor function by setting the timerto '24'. Here the light will stay on until manually turn off.

## How to set the timer:

- ①Connect to the transformer and lamps;
- ②Turn on the light sensor (the light sensor will start to work if the screen not flashing);
- ③Press down'-'or '+' button to set the timer (Set how many hours you need and then setting is done) ④When the illuminance  $\leq 20 \pm 10$  LUX, the 1amp will turn on and timer start to count down (Device in fast flash 3 times); the timer stops working until the lamp turning off;
- ⑤Set hours to '24' so that lamp keeps turning on.