


GARDEN 24 DIMMER

106937

Technical Data

Voltage	24V
IP Class	IP 44



How to set the dimmer:

- 1 Press the button on the dimmer to turn on the light.
Digital tube shows "00" : light off
- 2 There are 7 levels of light intensity in this dimmer.
Digital tube from "01" to "07", the light fades up step by step.
- 3 First press the light will be on at the first level of the light intensity and digital tube shows "01"
Second press the light will be lighter than the first press and digital tube shows "02"
Seventh press is the lightest and the digital tube shows "07"
Eighth press the light will be off.
You can choose the intensity of the light, and set it there.

Markslojd ÄB
Gränevägen 5 S-511 62 Skene
Sweden
www.markslojd.com

